

BEE-NAI<sup>LS</sup>



**GoBee**

USER MANUAL

## **GoBee** ACTIVE

In an urban setting or on your favorite trail, GoBee is there with you.

GoBee enables people to vaporize

anytime, anywhere. **GoBee** SOCIAL

Share your experience with friends and explore the world around you!

This is your adventure... **GoBee**

# 1. INSTALLATION

# 1. INSTALLATION

**Step 1:** Fully charge your battery with included micro USB charger for two hours, the light will remain red while charging and change to green when fully charged.

**Step 2:** Remove the glass mouthpiece from the heating chamber


**Step 3:** Fill the heating chamber with concentrate using the included Dabber/Packing Tool (**do not over pack**).

**Step 4:** Cover the glass mouthpiece back on to the heating chamber

YOU ARE NOW READY TO USE YOUR GOBEE!

**Step 5:** Tap the bottom button five times fast to power the unit on/off.

## 2. USE



Hold the button on the bottom of your unit to activate heating element. The green light indicates that your GoBee is ready to use. **Do not hold button down for more than 10 seconds as this will reduce the life of your GoBee.**

Your GoBee is equipped with a five tap protection/lockout function. If you have disabled the device and the button does not glow when you touch it, tap it five times in rapid succession to unlock and resume use.

**GoBee** 2

## 2. USE



Your GoBee has three temperature settings. You can switch between the three by tapping three times.

GoBee also has an adjustable airflow design. You can slide the airflow ring to adjust airflow according to your vaping needs.

## 3. CHARGING

After plugging the charger into the the battery a red light will turn on. Once the light turns green your battery is fully charged.

## 4. CLEANING

When using for an extended amount of time, the glass mouthpiece may become clogged and dirty resulting in reduced airflow. We recommend cleaning it with an alcohol swab. Please make sure to rinse your mouthpiece with water after cleaning and let dry. When cleaning the heating chamber we recommend a gentle brush to clean the walls, DO NOT push all the way down on to the heating element.



## 5. WARNINGS / TIPS

- DO NOT fill the heating chamber with any stems, seeds or liquids.
- DO NOT touch the heating chamber within two minutes after use.
- DO NOT put in any water or other liquid.
- For best results do not over pack the heating chamber, allow for proper air flow for even heating.
- In the event that no vapor is being produced, use the packing tool to gently stir the contents.

## 6. TROUBLESHOOTING

Q - I know my battery is charged but when I touch the button it does not light up.

A - You probably enabled the lockout feature. Tap the button five times in rapid succession.

Q - I draw/puff on my GoBee and the light flashes when I touch it?

A - The battery is probably low and needs to be recharged.

**For more troubleshooting tips contact us:**

Web: [www.bee-nails.com](http://www.bee-nails.com)

Email: [info@bee-nails](mailto:info@bee-nails)

Phone: 1-844-BEE-NAIL



# GoBee

[www.bee-nails.com](http://www.bee-nails.com)

